


**Telephone:**  
**Fax:**  
**VAT Registration No.:**

<b>Name:</b>		<b>Manufacturer:</b>	Ford
<b>Address:</b>		<b>Model:</b>	
		<b>Year:</b>	1989
		<b>Registration:</b>	
<b>Tel - Private:</b>		<b>Mileage:</b>	
<b>Tel - Business:</b>		<b>Job number:</b>	

X88	AC connector
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
W21	Octane coding plug
B147	Throttle position (TP) sensor
X79	Transmission connector
A19	Trip computer
B33	Vehicle speed sensor (VSS)



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

